


K70APT2GRCQ Pick-to-Light – Placement Sensor Capacitive Sensor



Technical data

K70APT2GRCQ
3096860
Pick-to-Light
Touch Button
Green Red
Green, Permanently on, 45 Im
Red
1230 VDC
≤ 150 mA
220 mA
NO contact, PNP
PNP
< 50 ms
Dome, K70
Dome, K70 Ø 70 x 103.5 mm
,
Ø 70 x 103.5 mm
Ø 70 x 103.5 mm Plastic, PC, Black
Ø 70 x 103.5 mm Plastic, PC, Black Plastic, diffuse
Ø 70 x 103.5 mm Plastic, PC, Black Plastic, diffuse Connector, M12 × 1, PVC
Ø 70 x 103.5 mm Plastic, PC, Black Plastic, diffuse Connector, M12 × 1, PVC 5



Features

Protection class IP65

M12 x 1 male connector, 4-pin

Job light: green

Mispick: -

Actuation: redOperating voltage 12...30 VDC


PNP switching

NO contact

Capacitive sensor of the second generation

 High immunity to false actuation by splashing, detergents, oils and other contaminants

Wiring diagram



Functional principle

The K70 pick-and-place sensor is suitable for many mounting and component placement applications. The green work light or other signal lights are reflected perfectly by the entire dome (depending on the version). The transistor output can be easily connected to a system control, which is programmed for a special task sequence. The work light of the sensor is located in or next to every bin at the operator's workstation and indicates: 1. The bins with the components to be picked up for a particular work step and 2. the sequence in which the components have to be picked up. If the operator removes a part from the bin, the K50 detects the hand in the bin and sends a signal to the control unit. The system then checks if the



Technical data

Tests/approvals

Approvals

CE, cULus listed

correct component has been picked up and – depending on the configuration – switches the corresponding work light off and the next one on, according to the assembly sequence. The work sequence control leads to increased efficiency, improved quality control and reduces rework and testing expenses. The term work light therefore refers to the visual indicator of the bin from which a part should be removed next. The actuation indicator confirms the removal with a different color. The mispick indicator illuminates if a bin was reached into when the work light was not set.

Accessories

